



INSTALLATION

Installation Instructions. FloorMat. Rev 12.13.12

- STEP 1** Make sure the subfloor is structurally sound, level and free from dust and debris. Check for protruding nails and/or defects in the subfloor. If installing over concrete, the concrete must be dry with moisture emission rate not exceeding 3lbs. Per 1000 square feet per 24 hours as measured by the Anhydrous Calcium Chloride Test.
- STEP 2** Start in the corner of the room and install the FloorMat™ parallel to the wall in the opposite direction as you plan to install the flooring planks. Install the FloorMat™ with the foil side up and the foam side facing the subfloor. When installing the FloorMat™, leave at least 2" going up the wall.
- STEP 3** Fold out the next row of FloorMat™ in the same manner making sure the foam seams are butted together.
- STEP 4** If installing the FloorMat™ on concrete or below grade subfloors, be sure to tape the seam together using FloorMuffler UltraSeal Seam Tape or an equivalent tape that meets the moisture vapor transmission requirements for this type of installation.
- STEP 5** Install the flooring per the manufacturer's instructions.

